



« STAND-OFF BIOLOGICAL DETECTION BY LIF (LASER INDUCED FLUORESCENCE) LIDAR »

***OPTRO 2010 – 4TH INTERNATIONAL SYMPOSIUM
OPTRONICS IN DEFENCE AND SECURITY***

4th February 2010

O. Meyer

C. Jacquelard, JM. Melkonian, P. Chardard, P. Lanson, D. Petitgas

CILAS


Outline

1. Context
2. Principle of LIF Lidar
3. Overview of current LIF developments
4. CILAS First studies in stand-off detection
5. Recent activity
6. Perspectives
7. Conclusion

1. Context

- Threat of biological attack is increasing
 - Terrorist attack
- Important benefit of a early warning system in term of countermeasure
 - Area evacuation
 - Individual protection
- Stand-off chemical detectors are available, but no stand-off biological detector (only local detector)
- Active developments under that field are investigated
 - LIF Lidar technology is one of the best candidate
 - Development either supported by Europe (European Commission) and the french MoD (DGA)
 - European Commission => BODE program
 - DGA => Perseïdes/Lidar Bio 2 program

2. LIV Lidar principle



3. Overview of current LIF developments

- Developments done by several countries
- UV laser emission
 - 355 nm
 - 266 nm
- Reception
 - Spectrometer coupled with
 - Photomultiplier Tubes
 - Intensified CCD
- Data processing for threat classification
 - Remains the more important challenge of this technology

	UV Emission	Reception
Canada	UV excimer laser 120-170 mJ/pulse @ 351 nm – rate = 125 Hz	Backscatter signal using photomultipliers Fluorescence signal using Intensified CCD + spectrometer
Germany	UV Solid State Laser 266 nm 355 nm	Information not released
Norway	UV Solid State Laser 150 mJ/pulse 355 nm – rate = 10 Hz	Backscatter signal using photomultipliers Fluorescence signal using Intensified CCD + spectrometer
UK	UV Solid State Laser 40 mJ/pulse 266 nm – rate = 10 Hz	Backscatter signal using photomultipliers Fluorescence signal using photomultipliers + spectrometer
USA	UV Solid State Laser 355 nm (at least)	Information not released

4. CILAS First studies in stand-off detection

- First studies in the 1980s with french MOD to develop a chemical LIDAR demonstrator
 - Short range lidar
 - CO₂ emission laser

- In the 1990s, MIRELA program in cooperation with the US to develop a high range chemical LIDAR
 - Tunable CO₂ laser
 - DIAL and DISC method
 - Classification range > 5 km

DETADIS



MIRELA



4. CILAS First studies in stand-off detection

- Studies continue to biological field at the end of the 90's
 - Lidar Bio : DGA program
 - Evaluation of biological stand-off capability through LIF Lidar
- Transportable system for field test
- Evaluation through 2 trials campaigns

Lidar truck and bio lidar working



Lidar set-up



5. Recent activity

2008-2009 : 2 projects

BODE (European Commission)


Perseïdes (DGA)

- BODE (Biological Optical Detection Experiment)
 - PASR FP6 program
 - 1st January 2007 to 31th March 2009
 - Consortium of 9 partners
- LIF Lidar demonstrator in the range of some 100s meters
- Development Steps
 - Identification of functional and operational requirements
 - System specification definition
 - Sub-assemblies specification, manufacturing, and tests
 - Demonstrator integration
 - Experimental trials: chamber demonstration then open field demonstration



BODE: Biological Optical Detection Experiment

- The emission with non linear crystals: a specific OPO (Optical Parametric Oscillator) setup has been built in order to produce the most effective UV wavelengths (**DLR**)
- Dual UV emission to improve capability cloud classification (2 cloud signatures)



BODE: Biological Optical Detection Experiment

- The optoelectronic reception: the emissions from fluorescent particles are collected into a telescope and directed to a multi-channels photomultiplier array via a series of dichroic filters (**BIRAL**)




BODE: Biological Optical Detection Experiment

- the Man Machine Interface (MMI) and data processing: A preliminary version of an operational MMI was developed, containing the principal information **(CILAS)**

« Operational MMI »




« Expert MMI »



BODE: Biological Optical Detection Experiment

- *Pictures of the overall demonstrator*



BODE: Biological Optical Detection Experiment

- Semi-closed chamber tests: the biological simulants were well localized and the concentration accurately measured and monitored,
- Open-air tests: biological simulants were sprayed in the atmosphere in order to generate a cloud, that the LIDAR were requested to detect and localize




(FOI, DGA/CEB, CILAS, BIRAL)



BODE: Biological Optical Detection Experiment


Backscattered signal

Fluorescence signal (1 channel)




BODE: Biological Optical Detection Experiment

- *Data analysis (1/2) : numerical filtration and ROC analysis for lidar sensibility estimation (DGA/CEB)*



BODE: Biological Optical Detection Experiment

- *Data analysis (2/2) : PCA algorithm processing for selectivity (cloud classification) estimation (FOI)*



5. Recent activity - BODE

- BODE conclusion
 - Complete evaluation of a LIF lidar (sensitivity, selectivity)
 - PCA classification seems promising
 - Dual UV excitation help to increase cloud classification (false alarm reduction)
 - Operational system need be to be optimised for low false alarm rate at the cost of false detection rate (real detection)
 - System R&T stage : TRL 4
 - Majors improvement points
 - Higher sensitivity
 - Higher selectivity
 - Lower size/weight

5. Recent activity - Perseïdes

- Perseïdes program
 - R&T DGA program for the development of new technologies against RBC (Radiological Biological Chemical) threat
 - 2009 - 2012
 - One part is dedicated to biological stand-off detection
 - Upgrade the biological lidar already developed, to increase sensitivity and selectivity capability, and range
 - Important efforts on new classification algorithms investigation (neuronal network, SVM, ...)
 - New field tests for validation in 2012

6. Perspectives

- The number of R&T program let hoping than in middle term, this technology will be available for system production (already the case in the US army)
- The sensitivity is less challenging than the selectivity (classification) capability
- Not only the use of several excitation wavelengths improves the classification capability
 - Depolarisation ratio can provide information about the aerosol shape
 - Wavelength ratio can provide information about the size range of the aerosol
- Short term improvements must also be focus on
 - Size
 - Weight

} Drive by the laser source technology

7. Conclusion

- The availability to get an early warning biological system drives the R&T programs in case of bio attack
- Except USA, all developments are on the status of demonstrator
- Most of the stand-off detection developments are based on LIF Lidar
- Signal processing and data analysis remain a challenge to push this technology on operational concept
- Availability to get operational system : middle term (5 years)